



Precision Rated Optics

Work with a PRO!

PRO-790

Fusion Splicer



Operation Guide

Table of Contents

1. Warnings and Cautions for Safe Operation.....	5
2. Description	7
2.1. Specification.....	7
2.2. Components.....	8
2.3. Accessory for Operation.....	8
2.4. Description and Function of Splicer.....	8
2.4.1. Main Body of Splicer:	8
2.4.2. Panel Keyboard	9
2.4.3. Power Supply Switch and Plugs.....	11
3. Detail of Splicing Operation	11
3. 1. Preparation before splicing operation.....	11
3. 2. Power Supply.....	11
3. 2. 2. Internal battery operation.....	11
3. 3. Power of Splicing Operation	11
3. 3. 1Power On.....	11
3. 3. 2. Standby Screen	12
3.4. Operation of Fiber Holders.....	12
3.5. Prepare and Place Fiber	14
3.5.1. Bare Fiber Prepare and Place.....	14
3.5. Setting Fiber in Splicer	16
3.5.2. Pigtail Preparing and setting.....	18
3.5.3. Drop cable preparing and setting.....	18
3.5.4. Patch cord preparing and setting	19
3.5.5. Splice on connector preparing and setting.....	20
3.6. Splicing operation.....	21
3.7. Fiber Removal	23
3.8. Reinforcing the Splice	24
3.9. Storing the fusion splicer.....	25
4. Maintenance of Splicing Quality	26
4.1 Cleaning and Checking before Splicing	26
4.1.1 Cleaning V-grooves.....	26

4.1.2 Cleaning Fiber Clamp Chips	27
4.1.3 Cleaning Mirrors surface	28
4.1.4 Program Test	29
4.2 Periodical Checking and Cleaning	29
4.2.1. Electrode Replacement	29
4.2.2 Cleaning Objective Lenses	30
4.2.3. Regular maintenance of battery	31
5. Menu Commands.....	31
5.1. Program Test	31
5.2. Selects Program	31
5. 3 Program Modify	32
5. 4Working type	33
5.4.1 AUTO working type.....	33
5.4.2 Manual working type.....	33
5.5. Heat time	34
5.6. PAUSE SET	34
5.7. Fusion Record.....	35
5.8. Language	35
5.9. Time Set	36
5.10. Gap Position	36
5.11. Maintenance Menu	37
5.11.1. Arc Times	37
5.11.2. System Test	38
5.11.3. Program Recover	38
5.11.4. Stabilize Electrodes	39
5.11.5. Maintenance Info.....	39
5.11.6. Check Dust	40
6. Transportation and storing	41
6.1. Warnings and Cautions for transportation.....	41
6.2. Storing require	41
6.3. Storing fusion splicer.....	41
7. Error Message List.....	42

8. Guarantee and Contact Address43
8.2. Guarantee period and limits.....43
8.2. Contact.....43

1. Warnings and Cautions for Safe Operation

- Read this manual carefully and completely before operating the splicer.
- Adhere to all safety instructions and warnings contained in this instruction manual.
- Retain this manual for future reference.

WARNING

- 1) Never operate the splicer in an environment where flammable liquids or vapors exist. Risk of dangerous fire or explosion may result from the electrical arc in such an environment.
- 2) Do not use the splicer near any hot equipment or in any place of high temperature .Possible equipment failure or fire may result.
- 3) Do not touch the splicer, AC power cord or AC plug if your hand is wet. Possible electric shock may occur.
- 4) Do not operate the splicer if water condensation is present on surface of splicer. This may result in electric shock or equipment failure.
- 5) The splicer is precision adjusted and aligned. Do not allow the unit to receive a strong shock or impact. Possible equipment failure may result. Use carrying case to transport and store the splicer. The carrying case protects the splicer from damage, moisture, vibration and shock during storage and transportation.
- 6) Do not place the splicer in an unstable or unbalanced position. The splicer may shift and lose balance, causing the unit to fall. Personal injury or equipment damage may occur.
- 7) Keep the splicer free from sand, dust, lubricants and other contaminants. The presence of such substances may degrade the splicing performance and cause equipment failure or damage.
- 8) Do not use any chemical other than alcohol to clean the objective lens, V-groove, mirror, LCD monitor, etc., of the splicer. Otherwise, blurring, discoloration, damage or deterioration may result.
- 9) The splicer requires no lubrication. Oil or grease may degrade the splicing performance and damage the splicer.
- 10) Do not use compressed gas or canned air to clean the splicer. They may contain flammable materials that may ignite during the electrical discharge.
- 11) Do not store the splicer in any area where temperature and humidity are extremely high. Possible equipment failure may result.
- 12) Before using the shoulder belt of carrying case, inspect the belt and hook for excessive wear or damage. Carrying the case with a damaged belt may cause it to fall and may result in personal injury or equipment damage.
- 13) Do not touch the electrodes when the splicer is on and power is supplied to the unit, the electrodes generate high voltage and high temperatures that may cause a severe shock or burn. Turn the splicer off, and disconnect the AC power cord, or remove the battery pack when replacing the electrodes. (Note: Opening the wind protector stops arc discharge.)
- 14) Use only the 100-240V AC, 50-60Hz/12V DC,14Ah with it. The proper supply voltage source is 100-240V AC, 50-60Hz, Check the AC Power source before use. Using an improper AC power source may cause fuming, electric shock or equipment damage and may result in personal injury, death or fire.

- 15) Use the supplied AC power cord. Do not place heavy objects on the AC power cord. Do not pull heat up or modify the AC power cord. Use of an improper cord or a damaged cord may cause fuming, electric shock or equipment damage and may result in personal injury, death or fire.
- 16) Connect the AC power cord properly to the splicer and wall socket. When inserting the AC plug, make sure there is no dust or dirt on the terminals. Incomplete engagement may cause fuming, electric shock or equipment damage and may result in personal injury, death or fire.
- 17) It uses a three-prong (core) AC cord that contains an earthed ground safety mechanism. The splicer **MUST** be Grounded/Earthed. Use only the supplied three-prong (core) AC power cord. **NEVER** use a two-prong (core) power cord, extension cable or plug.
- 18) Use only the approved battery pack with the machine. Only the battery pack can be used as the approved battery pack.
- 19) Use the specified charger cord to recharge the battery pack. Using other battery chargers and charger cords may cause fuming or equipment damage and result in personal injury, or death and it could cause a fire.
- 20) The splicer inlet is used to disconnect the power cord in the event of a fault. Be sure to position the splicer so that the power cord can be disconnected easily and quickly.
- 21) Disconnect the AC or DC power cord from the splicer inlet or the wall socket (outlet) immediately if the splicer or the external battery emits fumes, a bad smell, or becomes noisy or hot. Leaving the abnormal condition unattended will cause equipment failure, electric shock or fire and may result in personal injury, death or fire.
- 22) Disconnect the AC or DC power cord from the splicer inlet or the wall socket (outlet) immediately if liquid (e.g., water) or foreign matter (e.g., screw) enters the splicer. Leaving the splicer in a damaged state may cause equipment failure, electric shock or fire and may result in personal injury, death or fire.
- 23) Caution should be taken when removing the fiber protection sleeve from the tube heater after the heat shrink cycle is completed. The tube heater and fiber protection sleeve are hot and should not be touched. Possible burn may result
- 24) Replace the electrodes properly.
 - Use only specified electrodes.
 - Set the new electrodes in the correct position.
 - Replace the electrodes as a pair.

Disregard of the above instructions may cause abnormal arc discharge and result in equipment damage or degradation in splicing performance.

- 25) The equipment must be repaired or adjusted by a qualified technician or engineer. Incorrect repairs may cause fire or electric shock. Should any problem arise, please contact your nearest sales agency.

2. Description

2.1. Specification

Applicable Fibers	SM, MM, DS, NZDS, G655, G657
Fiber Diameter	Cladding Diameter: 80-150 μ m; Coating Diameter: 100~1,000 μ m
Average Splice Loss	0.01db (MM), 0.02db (SM), 0.05db (DS/NZDS/G.655/G.657)
Return Loss	60dB
Tension Test	2.0N (Standard)
Splice Time	8 Seconds
Sleeve Lengths	25mm, 40mm, 50mm
Sleeve Heating Time	35 Sec.
Splicing Programs	Automatic Settings
Alignment	Core Alignment (PAS Technology)
Splicing Method	Arc Splicing
Fiber Holder	Bare Fiber, Pigtails. Patch Cords. Splice-on Connectors (SC)
Monitor	3.5" Color TFT
Interface	USB
Languages	English, Chinese
Data Storage	10,000 Splice Results
Electrode Lifespan	\geq 5,000
Operating Temperature	-0.4 $^{\circ}$ F ~ 122 $^{\circ}$ F (-18 $^{\circ}$ C ~ 50 $^{\circ}$ C)
Storage Temperature	-40 $^{\circ}$ F ~ 176 $^{\circ}$ F (-40 $^{\circ}$ C ~ 80 $^{\circ}$ C)
Power Supply	Lithium Polymer Battery, DC Adaptor (12v) Battery Capacity: Approximately 150 Splices and Oven Uses
Environmental Conditions	0 ~ 95% (Humidity), 0 ~ 5000m (Altitude), 15mph (Max. Wind Velocity)
Weight & Dimensions (LxWxH)	4.8" x 4.8" x 5.1" / 4.5 lbs (122mm x 122mm x 130mm / 2.04 kg) w/Batt
Warranty	Standard 1-Year Manufacturer Warranty (Extended Warranty Available)

2.2. Components

Fusion Splicer, DC Charger, Spare Electrodes, Cooling Tray, Carry Case, Fiber Cleaver, Fiber Strippers, SOC (SC) Fiber Holder, Operating Manual

2.3. Accessory for Operation

Fiber Protection Sleeve, Stripper, Fiber Cleaver, Dispenser, Thin Cotton Swab, Lint-free tissue or Gauze

2.4. Description and Function of Splicer

2.4.1. Main Body of Splicer:



2.4.2. Panel Keyboard

Right Keyboard



Key	Name	Function
	Heat	Start/stop tube heater
	Start	Start splice operation
	Reset	Splicer Rest
	Shift	Shift up down, right left




Left Keyboard



Key	Name	Function
	Menu	Enter Main Menu Confirm Menu
	Exit	Exit
	Down	Menu: move cursor down Manual: move fiber down
	Up	Menu: move cursor Manual: move fiber up
	Confirm	Choose Program and confirm menu

2.4.3. Power Supply Switch and Plugs



3. Detail of Splicing Operation

3.1. Preparation before splicing operation

Prepare the necessary item.

3.2. Power Supply

The internal battery provides the power to machine.

3.2.2. Internal battery operation

Power on machine, internal battery will be used if AC adapter is not plugged in.

3.3. Power of Splicing Operation


- Check: Must clean and check the machine before operating.

3.3.1 Power On

Switch  to "1" Position



3.3.2. Standby Screen




- Note: Press to change working mode or program

3.4. Operation of Fiber Holders

- 1) The fusion splicer is equipped with a universal fiber holder. By adjusting, it can hold bare fiber, pigtail, drop cable and the SOC Fiber Holders has two fiber-placing positions.



Drop Cable



Pigtail



Bare Fiber



900 Bare Fiber


2) Change the Universal and SOC fiber holders by loosening the screw



Allen wrench



Pull or push driving level to change position



Pull or push driving level to change position




3) Change the SOC Fiber Holder for SOC Splicing operation as follows.

Loosen the Screw



Take off the fiber



Place the SC into Fiber Holder



3.5. Prepare and Place Fiber

3.5.1. Bare Fiber Prepare and Place

3.5.1.1. Clean the Outer Coating

Clean the fiber outer coating approx.100mm in length from the fiber end with alcohol-soaked gauze or lint-free tissue. If dust or other impurities on the outer coating enter the fiber protection sleeve, burnout or breaking of fiber may result after completion of installation.

3.5.1.2. Protection Sleeve operation

Pass the fiber through the fiber protection sleeve (Fig.3-2)




Fig 3-2




Fig 3-3

- 1) Remove the fiber coating 30-40mm with a stripping tool.
 - After this operation, handle the fiber so as not to damage the bare fiber
- 2) Clean the bare part with another alcohol tissue
 - Check: After this operation, handle the fiber so as not to damage the fiber
 - Check: Use a high quality alcohol with greater than 99% pure
 - Check: Change lint-free tissue each time



Fiber Cleaving

- 1) Open the cover and pressure pad. Put the stripped fiber on the V-groove. And make sure that the cleaver length is set as per operators' intended length.
- 2) Close the pressure pad to fix the fiber.
- 3) Close the cover and make sure that the end of the fiber is sticking out of the rubber pad exactly in a straight line.
- 4) Push the blade carriage to the rear until it stops.
- 5) Open the cover
- 6) Take out the cleaved fiber with care in order not to bring the harm to the end face of fiber.
- 7) For continuous operation, remove the cleaved fiber in this process. Be careful not to get injured by the cutting edge.





Fig3-4 Fiber Cleaving

3.6. Setting Fiber in Splicer

- 1) Open the wind protector.
- 2) Open the left and right sheath clamps.
- 3) Place fiber in the V-groove.
 - Check: Make sure the fiber is not twisted when setting it into the splicer.
 - Check: If the fiber coating has curl memory, or bend memory, load the fiber in such a manner that the crown (curve) of the memory is turn upward.
 - Check: Care should be taken to prevent damage or contamination of the fiber end-face. Fiber end-face contact on ANY item including V-groove bottom may result in poor quality splices.




Fig.3-5 Setting Fibers I

- 4) Gently close the sheath clamp while holding the fiber.
 - Check: Observe fiber setting in the V-groove. The fiber should rest in the bottom of the V-groove. Reload fiber if it does not rest properly.
 - Check: Fiber end-face should rest between the V-groove tip and electrode center line. It is unnecessary that the fiber end-face be exactly at the midpoint.





Fig.4-4 Setting Fibers II

- 5) Repeat steps 3 and 4 for second fiber.
- 6) Gently close the left and right fiber clamps.
- 7) Close the wind protector

3.6.2. Pigtail Preparing and setting

- 1) Prepare the pigtail
- 2) Place the pigtail fiber in cleaver, cleave length is 16mm




- 3) Place the prepared pigtail in Fiber Holder



- 4) Close the pressure pad and prepare the right side fiber

3.6.3. Drop cable preparing and setting

- 1) Prepare the drop cable as needed



- 2) Place the drop cable in cleaver, the cleave length is 16mm


- 3) Place the prepared drop cable in fiber holder



- 4) Close the pressure pad and prepare the right side fiber, then do following step

3.6.4. Patch cord preparing and setting


- 1) Prepare the Patch Cord



- 2) Place the patch cord to fiber cleaver and the cleaving length is 16mm




- 3) Place the prepared patch cord in fiber holder




3.6.5. Splice on connector preparing and setting

- 1) Prepare the spliced fiber on connector



Strip the SOC, keeping 1mm coating

- 2) Place the splice on connector in the fiber holder. Place in fiber cleaver and cleave



- 3) Place the prepared splice on connector into fiber holder



- 4) Close the pressure pad and prepare the right side fiber

3.7. Splicing operation

It uses image processing to identify abnormal conditions that sometimes occur during the splicing process. A small portion of these defects sometimes goes undetected and a poor quality splice occurs. Visually inspect the fiber image on the monitor to confirm acceptance or rejection during the various stages of the splicing process.

Start of splicing

Press  to move the left and right fibers forward. After completion of cleaning the arc discharge, the fibers stop at the predetermined position.

- Note: When the fiber are moving forward and they appear to hop up and down, contamination may be present in the V-grooves or the fiber surface, Clean the V-grooves and redo fiber preparation.

Cleave angle measurement and alignment operation

Visually examine the condition of the fiber end-face while the splicer is in operation or at a pause.

- Check: Even if no cleave angle error is displayed, press  and redo fiber preparation if the following cases occur.




Fig.3-7 Fiber End Face

When the threshold of cleave angle is exceeded, an error message is displayed: “Left Fiber End-face badness” or “Right Fiber End-face badness”. Redo cleave fiber.




Fig 3-8 Alignment

Heating with arc discharge

After aligning the fibers, the splicer will produce a high voltage arc discharge to fuse the fibers together. During arc discharge, observe the fiber image on the monitor screen. If some part of the image exhibits an extremely bright glow (hot spot), which is created by burning contaminants located on the surface or end-face of the fiber, there is a possibility that the fiber core will be deformed. Although deformation can be detected by the loss estimation function, a re-splice is recommended.





Fig.3-9 Fibers Being Spliced

Splice Inspection

When the spliced state is abnormal, the splicer displays an error message “Splice Lost”. Arc-splice is recommended.

- Note: It is best to perform an arc test at this stage for the splicer to determine the best program for the fiber type.



- Note: A slightly fat splice is normal. There is no problem with the splice loss and reliability.
- Note: White line or black line will appear on fiber's joint with fluorine and titanium. Because of optics, there's no effect to joint.

Splice loss estimating

The estimated splice loss is displayed on the screen.




Fig.3-11 Result of Fiber Splicing

In some cases the splice loss can be improved with the re-arc feature. Press the  after re-arc discharge.

- Note: There are cases when the splice loss will deteriorate after re-arc discharge

Storing splice result

Press  or open the wind protector and the splicer will automatically perform the proof test and stores the splicing result. In the memory of the CMOS chip of the splice result. PRO-790 can store 8000 item splice result

3.8. Fiber Removal

- 1) Open the wind protector
 - Check: Heater clamps should be open.
- 2) Open the left sheath clamp, holding the left fiber in your hand.
- 3) Open the right sheath clamp, holding the right fiber in your hand.
- 4) Remove the fiber from the splicer.

3.9. Reinforcing the Splice

- 1) Slide the fiber protection sleeve to the center of the splice.
 - Check: Make sure the splice point and fiber protection sleeve are in the center of the tube heater.
 - Check: Make sure the reinforcing material is placed downward.
 - Check: Make sure the fiber is not twisted.
- 2) While applying tension to the fiber, lower the fiber into the center of the heater.
- 3) Close the heater





Fig.3-12 Setting in Tube Heater

- Check: Check again to see that the splice point and fiber protection sleeve are in the center of the tube heater.
- 4) Press  to start a tube-heating cycle. Upon completion of heating the heater LED turns off.
 - Note: To abort the tube heating cycle, press 
 - 5) Open the left and right heater clamps. While applying tension the fiber, take the fiber out.
 - Note: On occasions the fiber protection sleeve may adhere to the bottom of the tube heater. Simply use a cotton swab or similar soft tip object to gently push the fiber protection sleeve to dislodge.

- 6) Visually check the splice reinforcement for bubbles and impurities (Shown in Fig.4-16). If unacceptable redo.



3.10. Storing the fusion splicer

- 1) Turn the switch to "0" position
- 2) Take off AC adapter
- 3) Fusion splicer is a technical instrument. Its carrying case is designed to protect it from the environment and transportation.
 - Check: Cut off the power before storing.
 - Check: Cleaning the crucial parts in time: Pickup camera, Lamp-house lens, Fiber press and V-groove, Wipe off the dust and dunghill.
 - Check: Would the LCD surveillance screen vertical vail, Entireness cling to the fusion splicer
 - Check: Unchain the having line put in the carrying case.
 - Check: Lift the fusion splicer cased the carrying case.
 - Check: Cased the other fittings and expendable, Lid and button the carrying case.
 - Note: Eliminate the liquid in the bottle in time if the alcohol bottle in the carrying case . For fear spill influence the facility.

4. Maintenance of Splicing Quality

4.1 Cleaning and Checking before Splicing

Critical cleaning points and maintenance checks are described below.

4.1.1 Cleaning V-grooves

If contaminants in the V-grooves, correct clamping may not occur, resulting in higher splice loss. The V-grooves should be frequently inspected and periodically cleaned during normal operation.

- 1) Open the wind protector and fiber clamps.
- 2) Clean the bottom of the V-groove with an alcohol-soaked thin cotton swab as shown in Fig. 4-1. Remove excess alcohol from the V-groove with a clean dry swab.
 - Check: Use a high quality alcohol, greater than 99% pure.
 - Check: Use a high quality alcohol, greater than 99% pure.
 - Check: Do not use excessive force when cleaning the V-groove. The V-groove may be damaged.




Fig.4-1 Cleaning V-grooves

- 3) If the contaminants in V-groove cannot be removed with an alcohol-soaked thin cotton swab, use a cleaved fiber end-face to dislodge contaminants from V-groove bottom. Repeat step 2 after this procedure.

4.1.2 Cleaning Fiber Clamp Chips

If contaminants are present on the clamp chips, correct clamping may not occur, resulting in poor quality fiber alignment splices. The fiber clamp chips should be frequently inspected and periodically cleaned.

- 1) Open up the wind protector
 - 2) Clean press stand surface with an alcohol-soaked thin cotton swab .Remove excess alcohol from the press stand surface with a clean dry swab
- Check: Use a high quality alcohol greater than 99% pure cotton swab fiber press stand cleaning fiber press stand.




Fig 4-3 Clean Pressure Foot



4.1.3 Cleaning Mirrors surface

If the mirrors surface becomes dirty, the core position may be incorrect due to decreased optical path clarity, resulting in higher splice loss.

- 1) Clean the mirror surface with an alcohol-soaked thin cotton swab as shown in Fig.4—4. Remove excess alcohol from the mirror surface with a clean dry swab.
 - Check: Use a high quality alcohol, greater than 99% pure.
- 2) Mirror should be clean and smudge free.







Fig 4-4 Clean Protector Mirror

4.1.4 Program Test

Atmospheric conditions such as temperature, humidity and pressure are constantly changing which create variability in the arc temperature. The splicer contains a temperature, humidity and pressure sensors that are used in a constant feedback monitoring control system to regulate the arc power at a constant level. Changes in arc power due to electrode wear and glass adhesion cannot be corrected automatically. Also, the center position of arc discharge sometimes shifts to the left or right.

Using fusion splicer at herein after conditions, Also discharge test: Highest temperature, Lowest temperature, Too desiccation, Too humidity, Electro deinferior, Different fiber connect, After cleanness and instead electrode, Or all condition are concurrence. Arc test according to specifically fusion program request discharge intensity, Self-regulation discharge parameter, And seed discharge high temperature area adjust fiber center station.

- 1) Program test need twain fiber. According to commonly fusion means vs fiber stripper, sever and placed
- 2) In wait for state, Press  enter “Setup Menu”, Fluctuate arrowhead move to “Program Test”, Press  start program test.
- 3) Program test automatically adjusts discharge intensity. Repeat test until screen display “Arc good”
- 4) After program test, Press  exit and return to automatism splicing state



4.2 Periodical Checking and Cleaning

In order to maintain the splicing quality of the splicer, the points of periodical inspection and cleaning are recommended.

4.2.1. Electrode Replacement

Electrodes wear with use and also must be cleaned periodically due to silica oxide buildup. It is recommended that the electrodes should be replaced after 1,000, a message prompting to replace the electrodes is displayed immediately after turning on the power. Using the electrodes without a replacement will result in higher splice loss and reduced splice strength.

Electrode Changing

- 1) Before cleaning the objective lenses, always turn off the splicer.
- 2) Remove the used electrode as in Fig 4-6
- 3) Clean the electrode and then place to the fusion splicer
 - Check: Use approved electrodes for the splicer
 - Check: Be careful not to damage the electrode shaft or tips when cleaning and installing in the splicer, any damaged electrodes should be discarded.

- Check: When installing the electrodes, tighten screws no more than finger tight while pushing the electrode collars against the electrode fixtures. Incorrect installation of the electrodes may result in greater splice loss or damage to the circuit.
- 4) Turn on the power, prepare and load fibers into the splicer, in standby, press  enter program, press  Start arc test




Fig 4-6 Electrode exchange

4.2.2 Cleaning Objective Lenses

If the surfaces of the objective lenses become dirty, normal observation of the core position may be incorrect, resulting in higher splice loss or poor splicer operation. Therefore, clean them at regular intervals. Otherwise, dirt may accumulate and become impossible to remove.

- 1) Before cleaning the objective lenses, always turn off the splicer.
 - 2) Gently clean the lens surface with an alcohol-soaked thin cotton swab as shown in Fig.4-7. Using a cotton swab, starting in the center of the lens, move the swab in a circular motion until you spiral to the edge of the lens surface. Remove excess alcohol from the mirror surface with a clean dry swab.
- Check: Use a high quality alcohol, greater than 99% pure.
 - Check: Be careful not to bend the electrodes.




Fig4—7 Cleaning Objective Lenses

4.2.3. Regular maintenance of battery

The Internal battery is lithium battery without memory, which could be charged at any time. The First charging operation should last 18 hours to increase battery functional efficiency. The later charging operation should last about 6 hours, the red indicator light means the charging is ongoing, when it turns to green, meaning the charging is completed. Fusion splicer will stop work when the battery voltage is under 9v.

- Attention: The fuse will break off when short-circuit occurred or the current is over than 15A. Please replace the broken Fuse and check the circuit.

5. Menu Commands

5.1. Program Test

Welding machine with a built-in discharge test system. Users should be regular operation, to ensure stable quality.

5.2. Selects Program

In standby state , press  enter Program , move  or  to select program, press  to confirm it

Move cursor to fiber type, press  to confirm, press  to exit

Types of Fiber:

SM = Singlemode

MM = Multimode

DS = Dispersion Shifted

NZDS – Non-zero Dispersion Shifted

G657 = G657

- Note: Different fiber should select conformable fiber type program, Otherwise shall arouse waste value augment or splicer be defeated.



Fig 5-1 Select Program

5. 3 Program Modify

In standby state , press  to enter program menu, move  or  to enter program select , press  to enter sub-menu of program select, press  to modify program

Press  or  to change parameter, press  to exit.




Fig.5-2 Program Modify

Function	Function Explain	Value area
PreArc Time	Prefuse Time	0~1
PreArc Power	Prefuse Power	0~250
Arc Time	Fusion arc time	0~10.0
Arc Power	Fusion arc power	0~250
Forward	Fiber move forward in fusion time	0~60
Fiber move forward in fusion time	Fiber move speed in fusion time	1~10
Cleave Angle	Fiber incise end-face angle	0~5.0
Re Re-Arc time	Re-arc interval	0~25.0

5. 4Working type

In standby state, press enter program menu, press enter fusion set, press or change work type (see Fig 5-3 work type) press confirm, press exit.




Fig5-3 Work Type

5.4.1 AUTO working type

Auto working type is the commonly used type,after clean and cleave fiber,the fusion splicer will automatically do splicing operation.

5.4.2 Manual working type

With this working type, alignment, arc...will operated by manual.

□Attention: No loss estimation in manual working type

Key	Name	Function
	Shift	Shift up down left and right
	Down	Move fiber down
	Up	Move fiber up
	Confirm	Select program
	Exit	Exit

5.5. Heat time

In Standby State , Press  enter“ Program Menu”, press  move the cursor to “ Fusion Set ” , use  or  move the cursor to heating time, press  enter, use  or  add or cut time (See Fig 5-4), After then press  exit




Fig5-4 Heating time

5.6. PAUSE SET

Open or close PAUSE. In standby state, press  enter program menu , press  to Fusion Set, move  or  to Pause Press  to open or close PAUSE function.



Fig 5-5 Pause SET

5.7. Fusion Record

Enter this menu, may check the last 8000 record Press  enter Program Menu, press  enter “Fusion Record” and choose “View Record”, Press  enter (Fig 5-6)



Fig 5-6 Fusion Record

5.8. Language

Press  enter Program Menu, press  to Machine Set menu, Press  enter Language , Press  or  choose language (See Fig5-7)




Fig 5-7 Language Set

5.9. Time Set

This is to Modify date and time. In Standby State , Press  enter Program Menu, press  to Machine Set, Press  to enter, press Press  or  to Time Set, press  enter time set (See Fig 5-8) .move cursor to the one need changed, use  or  cut or add, after then, press  exit.




Fig 5-8 Time Set

5.10. Gap Position

Press  enter “Program Menu” use  or  move cursor to Fusion Set, Press  enter gap position set. (See Fig5-9 Gap Position).





Fig 5-9 Gap Position

5.11. Maintenance Menu

Assist-functions and maintenance functions are included In Standby state , press  enter Program Menu, use  enter maintenance menu (See Fig5-10)。




Fig 5-10 Maintenance menu

5.11.1. Arc Times

“ Program Menu ” → “ Maintenance Menu ” → “ Arc Times ” (Fig5-11), it can check the arc times of machine, and can delete arc times record。




Fig 5-11Arc Times

5.11.2. System Test

In Standby State, press  enter program menu, →maintenance menu → System test (See Fig5-12) Press  start.




Fig5-12 System Test

5.11.3. Program Recover

In Standby State , Press  Enter“ Program Menu” →“Maintenance Menu”, use  or  move cursor to Program Recover, press  enter program recover (See Fig5-13) Use  or  move cursor to yes or no, press  confirm, press  exit.




Fig 5-13 Program Recover

5.11.4. Stabilize Electrodes

In Standby State, press  enter “ Program Menu” → “Maintenance Menu”, use  or  move the cursor to “stabilize electrode”, press  enter stabilize electrode.



Fig 5-14 Stabilize Electrode

5.11.5. Maintenance Info

In Standby State , press  enter “ Program Menu” → “Maintenance Menu”, use  or  move cursor to “ Maintenance Info ” , press  enter maintenance info (See Fig 5-15)




Fig 5-15 Maintenance Info

5.11.6. Check Dust

In Standby State , press  enter“ Program Menu” →“Maintenance Info”, use  or  move cursor“
Check Dust”, press  Check dust”(See Fig 5-16)




Fig 5-16 Check Dust

6. Transportation and storing

6.1. Warnings and Cautions for transportation

Fiber fusion splicer is a precision machine, via a exactitude adjust and level. Do not come under strong shake or collide or else work mangle. Using the carrying case transportation or storing, The carrying case be capable of protect the facility prevent mangle, Shake, Concussion.

Check the belt and pothook before used the belt schlep , Or else induce the person damage or the facility mangle. Do not set the fusion splicer at a instability or lopsided station, Or else be able to lose the facility balance and induce mangle.

If consign the equipment facility, Put in the carrying case and detach bale of the battery, When bale, The fusion splicer placed upwards and indicate the upwards mark, And inform the shipper item in time. For example: moisture-proof, Fireproofing, Defend high temperature, Defend inversion, Defend collide.

6.2. Storing require

- 1) Check the thing whether complete in the carrying case ,Mostly components comprise :
- 2) Fusion splicer is an exact and expensive instrument, Should set secure condition and commissioner safekeeping
- 3) Advice battery charge once of each month. If long time no operation, Also battery charge fix a date with prolong employ life.

6.3. Storing fusion splicer

Put in carrying case in time of the fusion splicer after fusion.

- 1) Cut off the power before storing.
 - 2) Cleaning the crucial parts in time: Pickup camera, Lamp-house lens, Fiber press and V-groove, Wipe off the dust and dunghill.
 - 3) Would the LCD surveillance screen vertical vail, cling to the fusion splicer.
 - 4) Unchain the having line put in the carrying case.
 - 5) Lift the fusion splicer cased the carrying case.
 - 6) Cased the expendable, Lid and button the carrying case.
- Note: Eliminate the liquid in the bottle in time if the alcohol bottle in the carrying case . For fear spill influence the facility.

7. Error Message List

Follow the remedy precisely as shown in the following lists. If it is not possible to eliminate the problem, there is the possibility of the splicer being faulty and the splicer may require service. Consult your nearest us with the following information:

- Model name of the splicer
- Serial number of the splicer
- Error message
- Situation when the error occurs

Error Message	Reason	Remedy
Replace left fiber Replace right fiber Replace both fibers	The left fiber is set too far back. The right fiber is set too far back. The left or right fiber is set too back.	Reset, Moves left fiber forward Reset, Moves right fiber forward Reset, Moves left/right fiber all forward Reset, Moves left or right fiber forward
Left cleave bad Right cleave bad Both cleave bad	Bad fiber end-face Dust or dirt on the fiber surface. “End-face angle” set up too strict Dust or dirt on the objective lens or the wind protector mirror.	Check the condition of fiber cleaver. When the blade is worn, rotate the blade. Put “End-face angle” loose to suitable degree Anew preparation fiber Lean the lens or mirrors
Please close the wind protector	Unable to start splicing when the wind protector opens.	The splicer automatically starts splicing after closing the wind protector
	The wind protector is opened during splicing operation.	Press  reset after closing the wind protector
Fusion failure	The fiber stuff amount is insufficient.	Increase stuff amount in the parameter setup menu
	The pre-fuse power is too strong.	Minish pre-fuse power in the parameter setup menu

8. Guarantee and Contact Address

8.2. Guarantee period and limits.

If the splicer becomes out of order within one year from the date of delivery, we will repair it free of charge. However, note that repairs will be charged for in the following cases regardless of the guarantee period:

- Trouble or damage due to natural disaster.
- Trouble or damage due to abnormal voltage supply.
- Trouble or damage due to mishandling.
- Trouble or damage due to handling in disregard of the operating procedures or instructions described in the instruction manual.
- Consumable items(discharge electrodes etc.)

Before sending the splicer, Please consult nearest us first.

Necessary information for the repair.

Attach papers to the splicer in order to inform us of details as described below.

- 1) Your full name, section, division, company, address, phone number, fax number and e-mail address.
- 2) Model name and serial number of the splicer.
- 3) Encountered Trouble
 - ·What state did your splicer get into and when?
 - ·What is its present state?
 - ·The state of the monitor and the contents of the relevant error message.

Support
support@precisionratedoptics.com



