

# QuickTreX® Fiber Optic Talk Set

## Basic User Guide \*Product comes with detailed guide

### 1. Overview

The QuickTreX® Fiber Optic Talk Set is designed for full-duplex voice communication over singlemode fiber optic cable.

### 2. Operating Instructions

1. Press the Power Button to turn the device ON or OFF.
2. Press the Source Button to enable the laser source.
3. Press the Communication Button to begin communication.
4. Press the Backlight Button to toggle display backlight.
5. Press the CW/Frequency Button to switch frequency modes.
6. Press the End Button to stop communication or disable the laser.

### 3. Safety & Maintenance

- Keep connectors clean.
- Use dust caps when not in use.
- Handle connectors carefully to avoid scratches.
- Clean adapters regularly for best performance.
- Remove batteries during long-term storage.

### 4. Best Practices

- Verify proper fiber connection before use.
- Use simplex singlemode fiber for secure communication.
- Avoid bending fiber cables.
- Store in protective case.

### 5. Important Notes

- Do not look directly into active fiber ports.
- Ensure connector compatibility (UPC to UPC).
- Use only compatible accessories.