LANshack

Working with MTP®/MPO:

Understanding connector types, strand counts, and polarity throughout.

Working with MTP®/MPO cable assemblies can be confusing, especially regarding polarity. But, for high density applications MTP is the best choice due to reduced labor costs, less congestion in cable pathways and spaces, and overall optical performance and reliability.

TABLE OF CONTENTS

MTP/MPO Polarity	
Method A – Straight Through	2
Method B – Fully Flipped (1-12, 12-1)	3
Method C – Pair Flip	3
MTP/MPO Connector Types	4
Male MTP/MPO Connector	4
Female MTP/MPO Connector	4
Connecting MTP Connectors	4
MTP Cassettes	5
For Method A or Method C Polarity:	5
For Method B Polarity:	6
Method B in Parallel Optics	6
Completing the Link	7
Method A Diagram	8
Method B Diagram	9
Method C Diagram	10
Our offerings	10



Working with MTP®/MPO cable assemblies can be confusing, especially regarding polarity. But, for high density applications MTP is the best choice due to reduced labor costs, less congestion in cable pathways and spaces, and overall optical performance and reliability.

Let's break down some common questions regarding MTP polarity methods.

MTP/MPO Polarity

Optical fiber networks require two fibers to make a complete circuit. The matching of the transmit Tx signal to the receive Rx equipment is referred to as polarity, and a transmit and receive side on optical transceivers usually use a duplex fiber connector to maintain the polarity. On most cabling systems, maintaining polarity just requires that the A side of one connector pair matches the B side of the other connector pair, with fiber connectors such as ST, LC, SC, and MTRJ.

MTP/MPO high density network design requires its own set of rules regarding maintaining polarity throughout the link. These three polarity methods are commonly referred to as Method A, Method B, and Method C, and we will discuss the difference further here.

Method A – Straight Through


This type of MTP cable has a key up key down position, and the fiber remains the same straight through the cable. Therefore each fiber is in the same position on each end of the cable. Fiber 1 in the cassette mates to Fiber 1 in the cable assembly, which mates to Fiber 1 in the end cassette.

The transmit/receive flip must happen with the patch cords either at the beginning or end of the link to ensure proper transceiver polarity.

Method B – Fully Flipped (1-12, 12-1)

This method utilizes a key up to key up position and this fiber cable is fully flipped on either end. This type of mating creates an inversion, where Fiber 1 is mated with Fiber 12, and Fiber 2 is mated with Fiber 11, etc. For these cables to preform properly, one of the cassettes would need to be inverted internally for Fiber 12 is mated

_			_
=	_		
-			
-			_



LANSHOCK .com

with Fiber 1 at the end of the link. This method requires two different cassettes with special labeling to identify which one is flipped.

This circuit is completed by using straight patch cords at the beginning and end of the link.

*Note- method B is not compatible with our standard QuickTrex cassettes.

Method C – Pair Flip

Method C and Method A are very similar, with the main difference being the flipping of the patch cords in the link. This method uses key up key down, and the polarity flip takes place within the cable itself. Each adjacent pairs of fiber at one end are flipped at the other end. So Fiber 1 and Fiber 2 becomes Fiber 2 and Fiber 1 at the other end, and so on.

This circuit is completed by using straight patch cords at the beginning and end of the link

METHOD C - PAIR FLIP

MTP/MPO Connector Types

Although most people in the industry refer to this connector as MTP, it is actually correct to also call it MPO. The term MTP is a registered trademark of USConec® and identifies their specific brand of the MPO-style connector.

The name MPO stands for Multifiber Push On, and typically consists of a 12 strand Ribbon Fiber that is terminated to a single compact push on connector.



Male MTP/MPO Connector

The **pins** on the MTP/MPO connector signifies that it is a **Male connector**.

The **white dot** on the right, signifies **position 1** on the MTP pinout.

The **raised tab** on the top of the connector signifies it is in the **key up position**.



Female MTP/MPO Connector



The **lack of pins o**n the MTP/MPO connector signifies that it is a **Female connector**.

The **white dot** on the right, signifies **position 1** on the MTP pinout.

The **raised tab** on the top of the connector signifies it is in the **key up position**.

MTP Strand Counts

There are three popular MTP strand counts available on the market today.



MTP 8

The MTP 8 Connector utilizes 8 of the 12 fibers in a standard 12 Fiber Connector. QSFP applications use the outer four fiber spots (1 – 4 and 8-12) of the MTP connector with four fibers used to transmit and four to receive. Method B is the most commonly used polarity method for a MTP 8.



MTP 12


• The MTP 12 Connector is the most popular choice for a MTP connector and is recognized as industry standard. Method A, B, and C are available in a MTP 12. Method A is the recommended polarity method.

MTP 24

• The MTP 24 is the most cost effective and high-density solution for MTP, as this connector is able to harness 24 fiber strands in one connector. There are various polarity options for MTP 24, but Method A is recommended, and is standard on our QuickTreX assemblies.

Connecting MTP Connectors

When connecting, or mating, two MTP connectors together, you will need an <u>MTP Adapter</u>, or for higher density applications a <u>MTP Adapter Panel</u> to accomplish this. The male connector should be in the key up position, and the female in the key down position as shown here:





MTP Cassettes

Maintaining proper polarity across your network is also applicable when choosing a cassette. Cassettes come in a few different forms: 12 Fiber (1 x 12), 24 Fiber (2 x 12), and 24 Fiber (1 x 24). It is especially important to make sure the MTP configuration on your MTP Trunk Assembly or MTP Fanout Assembly is compatible with the MTP Cassette you choose.

Cassettes will be labeled as Method A/C or Method B. The main difference here is orientation of the way the MTP cables are mated together. Alignment pins are pre-installed in the MTP/MPO connector located inside the cassette. These pins precisely align the mating fibers in the MTP/MPO connectors at either end of the cables that plug into the cassettes.

For Method A or Method C Polarity:

Method-A cassettes make a key up to key down connection between the internal MTP connector and the MTP cable connector.

• The cassettes will already be in a key up position, and when plugging in your MTP connector it needs to be in the key down position.

For Method B Polarity:

Method-B cassettes make a key up to key up, key down to key down connection. For these cables to perform properly, one of the cassettes would need to be inverted internally for Fiber 12 is mated with Fiber 1 at the end of the link. This method requires two different cassettes with special labeling to identify which one is flipped

- One cassette will be in the key up position, with the MTP cable also being key up.
- One cassette will be in the key down position, with the MTP cable also being key down.

Method B cassettes are not recommended for Singlemode APC fiber applications, because the angles of the mating connectors do not line up properly with this configuration and are not sufficient for low loss applications.

*QuickTreX cassettes support a method A/C configuration, and are not compatible with Method B.

Method B in Parallel Optics

Method B polarity is particularly useful in regard to 40G parallel optic applications, and direct switch to switch connectivity. Method B MTP cables are also referred to as a QSFP/QSFP+ cable or direct attach 40GBASE-SR4, 40GBASE-PLR4 or 40GBASE-PLRL4. This orientation is useful because instead of an



alternating Tx to Rx duplex pattern, 40G parallel optics utilizes the flipped Pin 1 to Pin 12, Pin 12 to Pin 1 pinout.

Female to Female type B trunk cables can also be used for a direct switch to switch connectivity going directly into 40G transceivers, or with an MTP adapter, used to connect a patch panel to a QSFP+ transceiver.

Completing the Link

We have talked about the different types of MTP polarities, and how to properly mate two MTP connectors. The last step in a standard MTP application is breaking out the high-density fiber strands into standard fiber connectors.

If you are using a cassette, then you will need standard fiber jumper cables to complete the polarity methodology. If you are using an adapter, then you will be connecting the MTP trunk cable to an <u>MTP</u> <u>fanout assembly</u> which will have standard fiber connector fanouts. The MTP Fanout Builder will go into more depth on configuration there, so let's focus on a MTP cassette method with patch cables.

There are two types of duplex fiber patch cables as defined in the TIA standard: A to A, and A to B. Maintaining proper polarity requires the B Tx signal to connect to the A Rx signal.

- A to B patch cables are also known as "straight-through"
- A to A patch cables are also known as "flipped"


Patch cords made with individual single fiber connectors at each end allow the flexibility for connections to be "swapped" when a polarity reversal is required.

• Our QuickTreX Custom USA fiber optic patch cables will provide the ability to be swapped.

The below diagrams are a macro overview of the entire MTP trunk cable to cassette connectivity flow. We have highlighted with a box, where the pairwise flipping (A to B swap) occurs in the MTP network.



Method A Configuration




METHOD A STRAIGHT THROUGH MTP TRUNK CABLE

This type of MTP cable has a key up key down position, and the fiber remains the same straight through the cable. Therefore, each fiber is in the same position on each end of the cable. Fiber 1 in the cassette mates to Fiber 1 in the cable assembly, which mates to Fiber 1 in the end cassette.

The transmit/receive flip must happen with the patch cords either at the beginning or end of the link to ensure proper transceiver polarity.



Method B Configuration



Method B - Fully Flipped (1-12, 12-1)

This method utilizes a key up to key up position and this fiber cable is fully flipped on either end. This type of mating creates an inversion, where Fiber 1 is mated with Fiber 12, and Fiber 2 is mated with Fiber 11, etc. For these cables to preform properly, one of the cassettes would need to be inverted internally for Fiber 12 is mated with Fiber 1 at the end of the link. This method requires two different cassettes with special labeling to identify which one is flipped.


METHOD B - FULL FLIPPED

This circuit is completed by using straight patch cords at the beginning and end of the link.

* Note- Method B is not compatible with our standard QuickTrex cassettes.



Method C Configuration



Method C - Pair Flip

Method C and Method A are very similar, with the main difference being the flipping of the patch cords in the link. This method uses key up key down, and the polarity flip takes place within the cable itself. Each adjacent pairs of fiber at one end are flipped at the other end. So Fiber 1 and Fiber 2 becomes Fiber 2 and Fiber 1 at the other end, and so on.

This circuit is completed by using straight patch cords at the beginning and end of the link



Our offerings

At LANshack we have been manufacturing custom fiber optic cabling with premium Corning Glass in the USA for over 20 years. Our QuickTreX custom line of MTP Trunk Cables, MTP Fanout Cables, MTP cassettes and enclosures are a complete robust solution for all your MTP needs.

Check out our MTP easy configurator tools to build your network today:

https://www.lanshack.com/QuickTreX-MTP-Assembly-Builder

https://www.lanshack.com/QuickTreX-MTP-Fanout-Builder

https://www.lanshack.com/QuickTreX-MTP-Cassettes

